Zip-Ez Installation Instructions

Zip-Ez™ Basic Installation

1 Use your battery drill.

2 Slip a Zip-Ez™ all-Purpose fastener over a screw.

3 Shoot it through with your drill.

Note: Extreme over-torqueing may cause cracking over time.

Zip-EZ™ For Installing Duct Wrap

1 To install duct wrap or fiber-free insulation with Zip-EZ™, wrap the duct work or wrap around the trunk duct.

2 Leave an overlap where the ends meet.

3 Secure with Zip-EZ™ fastener, covering the overlapping edges.

4 For the best results, use Zip-EZ™ all-purpose fastener every 8-12 inches.

5 Cover the seams & Zip-Ez with tape to insure a good vapor barrier.

This will secure the wrap permanently!

Note: For wrap thicker than 1.5″ use Zip-Ez™ face down.

J.T. Products, Inc. P.O. Box 626 Warwick, NY 10990
Phone 845.988.2000 Fax845.988.2001 Emailsales@jtproducts.com